

Chapter 37: Gable Vents



Using inward vent base edges as a guide, mark area to be cut on endwall steel **INSIDE**, make hole cut square with steel sheet (vertical cut lines parallel to steel ribs). Cut hole with appropriate tools.

Push vent base through hole in steel from inside.



Note word “TOP” on base when positioning. Vents installed with top side in any direction other than up will allow water to leak into building.

While holding vent base in place, snap face into base from steel exterior by pressing firmly.